

Nymi Band 3.0 - Strap Extenders

February 3, 2023 Version 2.0

Copyright © 2023 Nymi, Inc. All Rights Reserved.



TABLE OF CONTENTS

Revision History	3
Strap Extenders for Nymi Band	4
Background	4
Nymi Strap Extender	5
Installation Instructions	6



Revision History

Date	Version	Release Notes
April 5, 2021	1.0	February 3, 2023
February 3, 2023	2.0	Updated with new strap extender design



Strap Extenders for Nymi Band

Background

The Nymi Band[™] is a wrist-worn device that is designed to fit users with wrist diameters up to 210mm (8.25"), or approximately 99% of the population. For those users who find the Nymi Band too small to be comfortably worn, Nymi recommends the use of a Nymi Strap Extender as shown in the following sections. It has been validated for user comfort and compliance with product requirements. The Strap Extender will accommodate wrists up to 270mm (10.6") in diameter.

Additionally, some environments may forbid users from wearing the Nymi Band around their wrist to comply with safety requirements. In these instances, Nymi recommends using the Strap Extender to secure the band around the forearm or ankle.

Part number: 3400-02



Nymi Strap Extender





Installation Instructions



Slide the narrow end of the Strap Extender through the Nymi Band loop. Make sure the mushroom metal peg on the extender is pointing upwards.



Press metal peg through the hole in the Strap Extender to secure it to the Nymi Band.



Slide the sliding loop on the Nymi Band over the end of the Strap Extender.





Thread the strap through the Strap Extender loop.



Clasp the Strap Extender to the user's wrist. Remember to secure the strap with the sliding strap loop.



Adjust the strap and sliding loop for comfort.



Copyright © 2023 Nymi, Inc. All Rights Reserved.

Nymi, Inc. (Nymi) believes the information in this document is accurate as of its publication date. The information is subject to change without notice.

The information in this document is provided as-is and Nymi makes no representations or warranties of any kind. This document does not provide you with any legal rights to any intellectual property in any Nymi product. You may copy and use this document for your referential purposes.

This software or hardware is developed for general use in a variety of industries and Nymi assumes no liability as a result of their use or application. Nymi, Nymi Band, and other trademarks are the property of Nymi, Inc. Other trademarks may be the property of their respective owners.

Published in Canada. Nymi, Inc. Toronto, Ontario www.nymi.com