



Nymi Band Comfort

Increasing Comfort of the Nymi Band under PPE

2023.07.14

Connected in Confidence™

Nymi Band Comfort

The Nymi Band may be used in cleanrooms where users must wear many layers of personal protective equipment (PPE). Wearing the Nymi Band under multiple layers of gowns and gloves can become uncomfortable for the user.

Nymi has worked with customers and created some recommendations that address the issue of comfort with PPE.



Recommendation 1

Loosen the Nymi Band

The gloves and gowns are designed to fit very closely to the operator's wrist. When multiple layers of gowns and gloves are worn, they create more pressure on the Nymi Band, pushing it into the user's wrist. In some cases, the operator's hand can swell over time while the gloves are worn, further increasing discomfort.

One technique to improve comfort is to loosen the Nymi Band strap. The larger circumference of the strap will counteract some of the pressure from the PPE and therefore increase the user's comfort.

To wear the strap more loosely:

- Adjust the strap to the hole that fit snugly against the wrist
- Relax it by two or three stops, as shown in Figure 1
- Fasten the strap

Figure 1



Recommendation 2

Strap Extender

The gloves and gowns fit most closely near the operator's wrist where the PPE creates the most pressure on the Nymi Band.

The Nymi Band can be worn higher on the arm, avoiding the user's wrist where the PPE pressure is the greatest. The technique can be applied by using the Nymi Band Strap Extender, shown in Figure 2. This optional accessory increases the length of the Nymi Band's strap, allowing it to be worn higher on the forearm.

Once the Strap Extender is attached to the Nymi Band¹, the operator can wear it higher on the arm. The usage of the Nymi Band remains the same. The location of the NFC reader may need to change to ensure the operator can easily use the Nymi Band.

Figure 2



1. Please see the Nymi Band 3.0 Strap Extenders Guide for instructions on using the Strap Extender.



Questions?

Please contact your customer support representative.

www.nymi.com