



# Nymi Band Release Notes

Nymi Band 4

Nymi Firmware 5.0.3

2025-June-6  
Version 1

# Contents

---

Contents.....	2
Nymi Band 4.0.....	3
New In This Release .....	4
Backwards Compatibility .....	5
Upgrading to NF 5.0.3 .....	5
Known Issues and Limitations.....	6

Table 1: Revision History

Version	Date	Revision History
1	June 06, 2025	First release of document

# Nymi Band 4.0

---

The Nymi Band connects people with technology through safe, simple, and secure solutions. It supports numerous use cases and digital systems and combines point solutions into a single offering.

The goal is to simplify the connection of deskless workers to the digital space found in modern organizations. When the barriers to secure digital work are removed, workers can focus on what they do best.

Nymi Band 4 is a generational release at Risk Level 0. It can be used for use in production deployments or GxP environments.

## Nymi Band

Nymi Band 4 includes the following components:

- Nymi Band™ 4
- Nymi Band™ 4 Charger
- Nymi Band™ 4 Cradle
- Firmware version 5.0.3.10 for Nymi Band 4

## Nymi Documentation Package

Documentation has been updated for Nymi Band 4. For latest documentations visit the Nymi Support site.

- To access all the core documents, visit: <https://support.nymi.com/hc/en-us/sections/360004058491-Release-Documentation>
- To access all the secondary documents, visit: <https://support.nymi.com/hc/en-us/sections/360012100892-Supplementary-Product-Documentation>

## NFC Reader Support

NFC readers were not explicitly tested under the present release. For a list of NFC readers supported in this release, please refer to the [Supported NFC Readers](#) document.

## New In This Release

---

### Nymi Band 4

Nymi is launching a new product called **Nymi Band 4**. This product will replace Nymi Band 3 which is widely adopted in Pharmaceutical Manufacturing and adjacent markets. Nymi Band 4 improves comfort and usability, while remaining compatible with deployments of the Connected Worker Platform.

Nymi Band 4 uses a new charger and cradle. The cradle has been designed to fit the Nymi Power House so customers can adapt their existing deployments to accommodate Nymi Band 4.

**Please Note:** This release does not contain the Connected Worker Platform. At this time, the following releases support Nymi Band 4:

- CWP 1.19.1
- CWP 1.9.3
- CWP 1.17.2
- CWP 1.7.1

For more information on CWP, please refer to release notes for the desired version.

# Backwards Compatibility

Table 1: Backwards Compatibility Table

			Nymi Infrastructure			
			CWP 1.7.1	CWP 1.9.3	CWP 1.17.2	CWP 1.19.1
Firmware	Nymi Band 4	NF5.0.3	•	•	•	•

## Upgrading to NF 5.0.3

This is the first production release of firmware for Nymi Band 4. It will not run on Nymi Band 3.

## Known Issues and Limitations

---

Table 2: Known Issues in NF 5.0.3

Issue Number	Description
NF-4915	<p><b>Issue:</b> There is no haptic feedback when pressing the button when display is dim.</p> <p><b>Workaround:</b> The press will awaken the Nymi Band at which point it will respond to pressing of the button.</p>



Copyright © 2025  
Nymi Inc. All rights reserved.  
Published in December 2025

Nymi Inc. (Nymi) believes the information in this document is accurate as of its publication date. The information is subject to change without notice.

The information in this document is provided as-is and Nymi makes no representations or warranties of any kind. This document does not provide you with any legal rights to any intellectual property in any Nymi product. You may copy and use this document for your referential purposes.

This software or hardware is developed for general use in a variety of industries and Nymi assumes no liability as a result of their use or application. Nymi, Nymi Band, and other trademarks are the property of Nymi Inc. Other trademarks may be the property of their respective owners.

Published in Canada.  
Nymi Inc.  
Toronto, Ontario  
[www.nymi.com](http://www.nymi.com)